

## WQA series submersible sewage pumps(0.55-315kW)



- The cable adopts water-jet cutting technology (standard configuration for 11kW and above), which effectively prevents liquid water and moisture from entering the pump
- The pump adopts advanced hydraulic model. Most models have truly achieved full-heads, wide high-efficiency zones and stable performance
- Multiple detection and protection (standard configuration for 18.5kW and above), PTC, oil-water probe and float switch can all realize real-time detection and functions like alarm, shutdown, fault signals retention and so on
- Motor cavity can be checked through motor inspection hole without disassembling, and float switch can be replaced at any time
- Impeller nut adopts anti-reverse structure design
- Flexible handle, using tripod lifting, flexible in rotation, convenient, safe and firm
- 100% qualified before leaving factory, executive standard is GB/T3216

**Content**

○ Product description -----	01
○ Application scope -----	01
○ Working conditions -----	01
○ Product features -----	01
○ Technical descriptions -----	03
○ Installation dimension drawing -----	05
○ Attachment list -----	06
○ Standard wiring diagram of main control cable of WQA submersible sewage pump -----	09
○ Special monitoring device of WQA submersible sewage pump -----	12
○ Structure diagram of WQA products -----	13
○ Main materials and configuration table -----	14
○ Long-distance layout plan and cable specifications -----	16
○ Parameter table of WQA submersible motor -----	18
○ Installation method -----	21
○ Order description -----	21
○ Supply list -----	22
○ WQA50Hz performance curve chart -----	23
○ WQA installation dimension drawing -----	28
○ Flange coupling parts dimension table -----	28
○ Pump appearance and mobile installation -----	29
○ WQA installation dimension table -----	30
○ Installation instructions -----	35
○ Diving cable connection -----	35
○ Common malfunctions and solutions -----	37

**Product description**

WQA series submersible sewage pumps of Hangzhou XIZI Pump Industry, serve customers with better reliability and higher unit efficiency. Based on submersible pump manufacturing and experience accumulation of over 30 years, references and lead-in of international advanced hydraulic model design technology, XIZI pumps have achieved wide efficient zone, high efficiency and stable performance. Most pump models have realized full-heads, which completely solves customer's over-current problem. Meanwhile, comprehensive optimization in mechanical structure, sealing and protection, as well as high-quality motor material adoption, can ensure the stability of the unit. There are 182 models in WQA all series.

The product implements national standard of GB/T24674 《Submersible Sewage Pumps》 .

**Application scope**

Mainly used in municipal engineering, sewage treatment, building construction, water conservancy projects, industrial drainage, environmental protection, hospitals, hotels, etc.. Pumps are used for conveying waste water with solid particles and long fiber, sewage, rainwater, and also raw water transportation, aquaculture, irrigation, etc.

**Working conditions**

1. Flow rate: 7~4200m<sup>3</sup>/h
2. Head: 7~80m
3. Medium temperature: ≤40°C
4. Medium density: ≤1100kg/m<sup>3</sup>, the volume ratio of solid phase < 3%
5. Medium pH range: 4~10
6. The standard configuration of cable is 9 meters. You can specify in the order if other length is required. (Note: the voltage drop needs to be calculated)
7. Motor insulation class: F class (standard), H class (optional)
8. Protection level: IP68
9. Minimum operating liquid level: Refer to " " in the installation dimension drawing (no motor cooling system). Please call our technical department if user's liquid level is lower than " ".
10. The maximum diameter of solids in the medium should be less than the minimum size of the flow channel. The allowable passing solids diameters are detailed in the dimension table of specific pump model.

**Product features**

1. The impeller adopts closed structure with two main forms: ① Double channel type ② Vane type. The double-channel type impeller has good dirt passing performance. The vane type impeller is energy-saving and efficient.
  2. The pump unit has a compact structure and short shaft extension to reduce vibration and noise. It has undergone strict dynamic and static balance testing to reduce vibration value to the lowest point, and extend the expectancy life of bearing and mechanical seal.
  3. The cable adopts rubber flexible cable with good oil resistance and excellent mechanical performance, which can work continuously for a long time under 40°C. The interception capacity of the cable has sufficient margin to make the service life longer. The oil-resistant rubber flexible cable meets national standards of JB/T8735.2 and GB/T5013.4.
- The water-jet cutting cable prevents accidental water immersion in motor cavity. The pump end cable should be properly fixed to avoid dragging of the sealing device of lead-out wire of the motor upper cover cable .

4. The motor adopts high-performance squirrel-cage induction motor, which is specially designed and manufactured for submersible pumps. It implements GB755 standards. Protection class: IP68. Insulation class: F (standard), H (optional)

5. The shaft seal adopts single-end mechanical seal to completely isolate motor and pump. It is installed in series up and down to improve sealing reliability, and ensure the long-term and stable operation of pump. The designed service life of mechanical seal is 8,000 hours.

6. The bearing adopts lifelong maintenance-free rolling bearings. The upper bearing is deep groove ball bearing or cylindrical roller bearing, which is mainly used to bear radial force. The lower bearing is mainly used to bear radial force and axial force. Given that various pump models will generate different radial force and axial force, some are designed as a double-row angular contact ball bearing, and some are combinations of a diagonal contact ball bearing and a cylindrical roller bearing or deep groove ball bearing to ensure sufficient load margin, making the pump unit run smoothly. The designed service life of the bearing is 10,000 hours.

7. Oil chamber: Adopt 32# engine oil which can lubricate mechanical seal and cool down the bearing. Executive standard is GB443-89.

Add oil till it overflows from the filling hole to ensure that there is a certain gap in the oil chamber, so that the pressure will not rise significantly when oil temperature rises. This is to protect the mechanical seal in oil chamber, thereby protecting the motor.


8. Temperature measuring element (thermal protector is equipped for 3kW and below): Each phase winding is pre-embedded with temperature measuring element PTC (135°C). When the pump is in abnormal working condition, and the motor winding temperature rise reaches the setting value, the temperature measuring element will work, the "overheating" indicator light on control cabinet will be turned on, the pump will stop working. This reminds the operator to check and find out overheating causes and solutions in time.

The pump can recover by itself after the winding temperature drops.

9. Water leakage probe: The water leakage probe is used for leakage detection. When the mechanical seal or the sealing at impeller side is leaking, and the water amount in oil chamber is large to a certain extent, the two electrodes of the probe will be turned on and an alarm signal will be issued (the indicator lights on), to remind the operator to check mechanical seal in time and check whether the oil in oil chamber need to be replaced.

10. Float switch: The float switch is installed in the empty cavity next to the bearing cavity on the lower side of motor. It is used to check whether the mechanical seal in oil chamber is damaged and whether the motor seal is leaking. When the water amount in the float switch cavity reaches a certain level, the float switch will float and send an alarm signal through control cabinet (the indicator lights on), to remind the operator to check mechanical seal and motor sealing system in time.

Structural diagram of water-jet cutting cable



## Technical descriptions

### 1. Model definition

150 WQA 150-22-15-4P-Z

Installation Z: Automatic coupling installation

Y: Hard pipe mobile installation

R: Soft pipe mobile installation

P: Fixed base installation

Motor pole

Motor power(kW)

Head(m)

Flow(m³/h)

WQA series submersible sewage pump

Tubing diameter

2. WQA can be equipped with flange coupling which implements GB/T17241.6-2008 standard. The standard configuration for coupling outlet flange DN250 and below is PN6 and for DN300 and above is PN10. Pump outlet flange pressure rating is detailed in related pump page.

3. For WQA submersible sewage pump 7.5kW and below, pump can be equipped with stirring (JY)

4. The standard motor rated voltage of submersible sewage pump is 380V, and the rated power is 50Hz.

- ① 11kW and above can be customized with frequency 30~50Hz frequency conversion electric pump unit.
- ② The 60Hz electric pump unit can be customized.
- ③ Electric pump units with three-phase voltage below 690V can be manufactured.
- ④ Single-phase 220V can be manufactured for WQA 2.2kW and below.
- ⑤ Frequency conversion can be used for WQA 7.5kW and below.
- ⑥ Three-phase 220V can be manufactured for WQA 3kW and below.

5. Wiring method and starting method of motor winding lead wire

① The Y-shaped wiring method is used for 3kW and below. The stator lead-out wire and a main cable have been connected in the wiring cavity with this method. It can use direct start.

② The internal delta ( $\Delta$ ) wiring method is used for 4-315kW. When the pump leaves the factory, the winding wires and 1, 2, 3, and 4 main cables have been connected in the wiring cavity according to power level. Based on the power grid capacity and load permit on customer's site, direct start, external electronic soft starter start or auto-coupling step-down start can be adopted accordingly. (Please refer to wiring diagram for the number of main cable)

③ Single-phase 220V electric pump (0.55-2.2kW) adopts capacitor operation, double capacitor + centrifugal switch start.

④ If there are other requirements (eg: Star Delta Start Y-), please specify separately when placing an order.


### 6. Pump rotation direction

The impeller rotates counterclockwise looking from pump inlet. The impeller rotates clockwise looking from the motor.

7. When the liquid level difference is large on customer's site, use two float switches to control the start/stop liquid level for main pump or large pump, while using one float switch for small pump or standby pump under super high liquid level.

8. The terminal box can be installed on the spot when electric control cabinet is far away. When threading pipe (user owned) needs to be laid, confirm the inner diameter of the threading pipe according to the outer diameter of the cable.

### 9. Diagram and description of performance curve



The solid line part of the curve in the figure represents the reasonable pump operation range where pump efficiency is relatively high and economical.

When pump is running below the leftmost side of the solid line:

(1) Under long-term low-flow operation, the pump will be always in a state of holding pressure with high pump temperature, excessive vibration and shortened life. When the deviation from the reasonable working range is large, the pump will be damaged to a certain extent after long-term operation.




(2) Large radial force will be generated, bearing and mechanical seal damage is accelerated, rolling keys or even shaft breakage risk will be caused.

(3) The efficiency will drop and electric energy will be wasted.

When pump is running higher than the rightmost side of the solid line: The pump will have problems like vibration, noise, cavitation, even over-current and motor burning , etc.


### Installation dimension drawing

Dimension drawing of coupling installation Z





Flange implementation standard:GB/T17241.6


Hard pipe installation Y



Soft pipe installation R



1. The coupling railings are all fixed with expansion bolts which implement JB/ZQ4763-2006 standard. When the length of guide rod is bigger than 5 meters, it is recommended that the user fix the guide rod every 3 meters.
2. Calculate guide rod length according to the "pool depth" shown on the figure, and refer to the attached table for the length.
3. Δ indicates the minimum liquid level of pump operation. The pump operation liquid level should be higher than the minimum liquid level. It is best to submerge the pump completely under allowable site conditions, so that the motor can be fully cooled by the medium. The minimum liquid level can be controlled by float switch, ultrasonic level gauge, etc.
4. The dimension of coupling base and pump outlet flange shall comply with GB/T17241.6 standard.

**Attachment list**

Flange dimension table (6kg)						Soft pipe joint			Hard pipe joint (flange joint)		
D	D1	K	n-Φd1	h	h1	h2	D2	L1	L2		
40	130	100	4-Φ14	11	14	100	41	60	100		
50	140	110		12	16		50	65	110		
65	160	130		18	135	63	75	120			
80	190	150	4-Φ19	14	145	74	85	130			
100	210	170		15	170	99	105	145			
150	265	225		18	200	149	135	220			
200	320	280	8-Φ19	20	22	290	198	180	315		
250	375	335		23	24	340	253	225	395		

Flange dimension table (10kg)					Hard pipe joint (flange joint)	
D	D1	K	n-Φd1	h1	L2	
200	340	295	8 - Φ23	24	315	
250	395	350	12 - Φ23	26	395	
300	445	400	12 - Φ23	28	475	
350	505	460	16 - Φ23	28	550	
400	565	515	16 - Φ28	30	625	
500	670	620	20 - Φ28	32	700	

Anchor bolts (for coupling base)			Expansion bolt
Executive standard: (GB/T799-1988)/UDC621.882.6			Executive standard: JB/ZQ4763-2006
Diameter of Pump outlet(mm)	Model	Reference size of reserved hole Length × width × depth	Model
40	4-M12×220	80×80×300	2-M12×110
50			
65			
80		80×80×350	
100			
150			
200			
250			
300		100×100×450	
350	4-M20×400		2-M16×110
400			
500	4-M24×500	150×150×600	

Specification and dimension of pump guide rod (seamless steel pipe/tap water pipe) Executive standard (GB/T17395-2008)			
Diameter of Pump outlet(mm)	Specifications and dimensions of guide rod	Height from coupling base guide rod to the bottom(mm)	Weight of Guide rod (kg)
40	1"/Φ33×3 (Outer diameter × wall thickness)	14	2.3kg/m
50		16	
65		18	
80		390	
100		440	
150		450	
200	1.5"/Φ48×3 (Outer diameter × wall thickness)	570	3.33kg/m
250		680	
300		775	
350		900	
400			
500	2.5"/Φ76×3.5(Outer diameter × wall thickness)		

Reference length of guide rod=Pool depth-Height from coupling base guide rod to the bottom ± 20mm

(Flange coupling) accessory weight table (standard HT200)			
Diameter of Pump outlet(mm)	Complete set of coupling(kg)	Soft pipe joint (kg)	Hard pipe joint (kg)
40	10	1.4	2.7
50	16	1.6	2.9
65	21	2.3	5.2
80	27	3.3	7.8
100	38	4.8	9.4
150	107	9.6	16
200	135	30.5	30
250	195	46	47
300	320		68
350	410	/	/
400	742		/
500	780		

◎Note: The complete set of coupling includes coupling base, coupling gusset plate, coupling rod and does not include guide rails, hoisting chains, etc.

Steel short link chain and lifting chain executive standard: GB/T24814-2009 (grade 4 ordinary precision chain)

Optional table of grade 4 steel short link chains and lifting chains		
Nominal size of lifting chain (mm)	Nominal size × inner length × outer width (reference value)	Ultimate working load (t)
5	5×25×18	0.4
6.3	6.3×32×22	0.63
8	8×40×28	1
10	10×50×35	1.6
12.5	12.5×63×44	2.5
14	14×70×49	3.2
16	16×80×56	4
18	18×90×63	5
20	20×100×70	6.3
25	25×125×88	10
28	28×140×98	12.5

◎Note: 1. When customer chooses lifting chain, it needs to be selected according to the balance of more than 2 times of pump weight.(For safety, the balance needs to be increased when pump weight is more than 1 ton. )


2. There is no national standard for stainless steel (304, 316) lifting chains. If you need to purchase, you need to leave enough load margin to ensure safety.

3. If customers have special requirements, they can place an order with remarks separately.

◎Note: The default standard configuration is grade 4 precision. Order remarks are required if you need grade 8.


### Standard wiring diagram of main control cable of WQA submersible sewage pump

Standard wiring diagram (3kW and below, with thermal protection): Y type(1 main cable)




1. Motor coil
2. Motor protector is built-in normally closed passive switch
3. Power cord

Standard wiring diagram (4kW-315kW): internal delta type 4kW-15kW (1 main cable)




1. Motor coil
2. Power cord

18.5kW-37kW/4P 18.5kW-22kW/6P、8P  
(1 main cable, 1 control cable)




S1/S2 is the overheating protection line  
S3 is the water leakage protection line  
S4 is the public line  
S5 is the oil leakage protection line

1. Motor coil
2. Motor protection device (thermistor), is a normally closed passive switch signal
3. Immersion detector (float switch), is a normally open passive switch signal
4. Oil leakage detector (electrode), is a normally open passive resistance signal
5. Power cord
6. Control cord




S1/S2 is the overheating protection line  
S3/S4 is the water leakage protection line  
S5 is the public line  
S6 is the oil leakage protection line

1. Motor coil
2. Motor protection device (thermistor), is a normally closed passive switch signal
3. 4 . Immersion detector (float switch), is a normally open passive switch signal
5. Oil leakage detector (electrode), is a normally open passive resistance signal
6. Power cord
7. Control cord




Note: U1, U2 and U3 are combined into one line to connect to power supply of control cabinet.  
V1, V2 and V3 are combined into one line to connect to power supply of control cabinet.  
W1, W2 and W3 are combined into one line to connect to power supply of control cabinet.  
G1, G2 and G3 are combined into a line to connect to power supply of control cabinet.



S1/S2 is the overheating protection line  
S3/S4 is the water leakage protection line  
S5 is the public line  
S6 is the oil leakage protection line

1. Motor coil
2. Motor protection device (thermistor), is a normally closed passive switch signal
3. 4 . Immersion detector (float switch), is a normally open passive switch signal
5. Oil leakage detector (electrode), is a normally open passive resistance signal
6. Power cord
7. Control cord

Note: U1 and U2 are combined into one line to connect to power supply of control cabinet.  
V1 and V2 are combined into one line to connect to power supply of control cabinet.  
W1 and W2 are combined into one line to connect to power supply of control cabinet.  
G1 and G2 are combined into a line to connect to power supply of control cabinet.



Note: U1, U2 and U3.U4 are combined into one line to connect to power supply of control cabinet.  
V1, V2 and V3.V4 are combined into one line to connect to power supply of control cabinet.  
W1, W2 and W3.W4 are combined into one line to connect to power supply of control cabinet.  
G1, G2 and G3.G4 are combined into a line to connect to power supply of control cabinet.

## Special monitoring device of WQA submersible sewage pump

### 1. Purpose and function

XIZI submersible pump monitoring device (comprehensive protector) is an optional accessory specially designed for submersible pump protection device by our company, to realize the comprehensive protection function of the submersible pump.

It has monitoring and protection functions of motor stator temperature overheating (overheating), oil chamber water leakage (oil and water), wiring cavity and motor cavity water leakage(water leakage). It can monitor 2 pumps at the same time.

### 2. Specifications and technical parameters




#### 1. Specifications

Length × width × height: 115×90×40  
Installation size: 105×70, 4-Φ5; or install on the rail

#### 2. Working environment

Ambient temperature: -20°C~50°C;  
Relative humidity ≤ 85% RH; There is no corrosive gas in the surrounding environment  
3. Power supply: AC220V 50Hz

### 3. Electrical principle and terminal wiring diagram



1. 220V access "AC 220V"

2. This product can monitor two water pumps at the same time. You can choose to connect to port ① or ② when there is only one pump.

3. The common wires of the "overheating", "oil water", "leaking" lead-out wires and the PCC lead-out wires, form the respective protection and monitoring circuits (Refer to schematic diagram).



4. "Action output" can be connected to "NO output" or "NC output" according to customer site.

#### 4. Points for attention.


The inside of the monitoring device is full of electronic circuits, and the insulation resistance value cannot be measured with a megohmmeter.

## Structure diagram of WQA products

### Structure diagram for 7.5kW and below



### Structure diagram for 11kW and above



**Cable:** The water-jet cutting cable prevents accidental water immersion and adopts rubber flexible cable with good oil resistance and excellent mechanical performance. The pump end cable should be properly fixed to prevent dragging of the lead-out wire sealing device of the motor upper cover cable. Executive standard: JB/T8735.2 and GB/T5013.4

**Motor:** Dedicated squirrel cage induction motor, implementing standard GB755, protection grade is IP68, insulation grade (standard), H grade (optional).

**Motor inspection hole:** Located in the middle of the oil chamber, which can realize quick inspection and maintenance without disassembly.

**Oil chamber:** 32# engine oil is installed inside which has the function of lubricating mechanical seal and cooling. Executive standard: GB443-89

**Flexible handle:** using tripod lifting, the handle can be flexibly rotated, convenient, safe and firm.

**Multiple detection and protection:** PTC, oil-water probe and float switch can all realize real-time detection and functions like alarm, shutdown, fault signals retention and so on, to minimize the risk of failure. Refer to ①②③

**Mechanical seal:** Two independent single-end mechanical seals completely seal and isolate the motor and pump. It is installed in series up and down to realize double protection to ensure the safety of the motor. The designed service life of mechanical seal is 8,000 hours.

**Bearings:** Adopt various matching forms to ensure sufficient load margin to ensure smooth operation of the unit. The designed service life of the bearing is 10,000 hours.

**Factory inspection:** Every pump is tested before leaving the factory. Executive standard: GB/T3216


### Main materials and configuration table

WQA 7.5kW and below			
No.	Name	Standard	Optional
1	Volute (pump body, pressurized water chamber)	Ht200	/
2	Impeller	HT200	304
3	Oil chamber cover	HT200	/
4	Oil chamber, Motor frame, Pump cover, Upper cover, Pump base	HT200	/
5	Motor insulation class	F (155°C)	H (180°C)
6	Shaft	2Cr13	/
7	Bearing brand	Domestic	SKF、NSK
8	Mechanical seal	Brand	Domestic
9		Motor side friction pair	Graphite/SiC AQ1
10		Pump side friction pair	SiC/WC Q1U1
11		Spring	Stainless steel
12		Rubber parts	NBR
13	O-ring	NBR	FKM
14	External leakage fastener	8.8	A2-70
15	Protection device (optional)	0.55kW-7.5kW / Thermal protector for 3kW and below	Water leakage probe Float switch Overheating protection

WQA 11kW and above				
No.	Name	Standard	Optional	
1	Volute (pump body, pressurized water chamber)	HT250	QT	
2	Impeller	HT250	304 QT	
3	Oil chamber cover	HT250	QT	
4	Oil chamber, Motor frame, Pump cover, Upper cover, Pump base	HT250	/	
5	Motor insulation class	F (155°C)	H (180°C)	
6	Shaft	2Cr13	/	
7	Bearing brand	Domestic	SKF、NSK	
8	Mechanical seal	Brand	Domestic	Bergman
9		Motor side friction pair	Graphite/SiC AQ1	SiC/WC Q1U1
10		Pump side friction pair	SiC/WC Q1U1	/
11		Spring	Stainless steel	
12		Rubber parts	NBR	FKM
13	O-ring	NBR	FKM	
14	External leakage fastener	A2-70	/	
15	Protection device	18.5kW-315kW (Standard) 11kW-15kW (Optional)	Water leakage probe Float switch Overheating protection	Optional bearing temperature and vibration sensor

### Long-distance layout plan and cable specifications

**Long-distance layout plan:** When the control cabinet is far away from pump room, a terminal box can be installed, which makes the operation more convenient.



Specification/model of WQA submersible motor cable						
Motor power(kW)	Cable model	Standard main cable specification	star delta	Specification/model of controlling cable		
0.55	YZW 300/500V	YZW 4×0.75	/	YZW 4×0.75 (Non-standard)		
0.75						
1.1		YZW 4×1				
1.5						
2.2		YZW 3×1.5+1×1				
3						
4		YZW 3×2.5+1×1				
5.5						
7.5		YZW 3×6+1×4	2-YZW 3×2.5+1×1	YZW 4×1(Non-standard)		
11/15-2						
11/15-4/6		2-YZW 3×6+1×4	YZW 8×1(Non-standard)			
18.5/22-2						
18.5/22-4/6		YCW 3×10+1×6	2-YCW 3×10+1×6	YZW 8×1 (Standard )		
30/37-2						
30-4/6/8		YCW 3×16+1×6	2-YCW 3×16+1×6			
37-4/6/8						
45-4/6		YCW 3×25+1×10	2-YCW 3×25+1×10			
45-8、55						
75-4		YCW 3×35+1×10	2-YCW 3×35+1×10			
90-4						
75-6/8		2-YCW 3×25+1×10	2-YCW 3×25+1×6			
90-6/8						
110		YCW 3×50+1×16	2-YCW 3×35+1×10			
132						
160-4/6		2-YCW 3×70+1×25	2-YCW 3×35+1×10			
160-8						
200-4/6、185		3-YCW 3×50+1×16	2-YCW 3×50+1×16			
200-8						
220-4/6/8		3-YCW 3×70+1×25	2-YCW 3×50+1×16			
250-4/6/8						
280-4		4-YCW 3×50+1×16	/			
280-6/8						
315-4/6/8						

### Parameter table of WQA submersible motor

Parameter table of submersible motor(single-phase 220V 50Hz)								
No.	Motor power (kW)	Pole number	Rated current A	Power factor cosψ	Motor efficiency %	Locked-rotor currentA	Rated torque N.M	Locked-rotor torque
1	0.55	2	5.2	0.92	70	15	1.88	1.7
2	0.75		5.4	0.92	72	20	2.56	
3	1.1		7.8	0.95	75	30	3.73	
4	1.5		10.2	0.95	76	45	5.1	
5	2.2		14.7	0.95	77	65	7.42	

Parameter table of submersible motor(three-phase 220V 50Hz)								
No.	Motor power (kW)	Pole number	Rated current A	Power factor cosψ	Motor efficiency %	Locked-rotor currentA	Rated torque N.M	Locked-rotor torque
1	0.55	2	3.2	0.82	73	14.03	1.87	2.2
2	0.75		3.5	0.83	75	18.88	2.53	
3	1.1		4.4	0.84	77	30.14	3.71	
4	1.5		6.3	0.84	79	40.53	5.03	
5	2.2		8.5	0.85	81	56.81	7.38	
6	3		11	0.87	83	79.85	9.96	

Parameter table of submersible motor(three-phase 380V 50Hz)								
No.	Motor power (kW)	Pole number	Rated current A	Power factor cosψ	Motor efficiency %	Locked-rotor currentA	Rated torque N.M	Locked-rotor torque
1	0.55	2	1.8	0.82	73	8.1	1.87	2.2
2	0.75		2	0.83	75	10.9	2.53	2.2
3	1.1		2.5	0.84	77	17.4	3.71	2.2
4	1.5		3.6	0.84	79	23.4	5.03	2.2
5	2.2		4.9	0.85	81	32.8	7.38	2.2
6	3		6.4	0.87	83	46.1	9.96	2.2
7	4		8.2	0.88	85	58.7	13.24	2.2
8	5.5	2	11	0.88	86	80.3	18.09	2.2
9	7.5		12	0.83	85	80.5	36.4	2.3
10	11	2	15	0.88	87	106.5	24.66	2.2
11	15		16	0.84	87	107.1	49.63	2.3
12	22	2	22	0.89	88	156.8	35.81	2.2
13	23	4	23	0.84	88	155.4	71.85	2.2
14	29	2	29	0.89	89	209.3	48.84	2.2
15	30	4	30	0.85	89	223.5	97.97	2.2
16	31	6	31	0.81	91.2	225.6	147.2	2
17	34	8	34	0.76	88	219.8	196.2	2

Parameter table of submersible motor(three-phase 380V 50Hz)									
No.	Motor power (kW)	Pole number	Rated current A	Power factor cosψ	Motor efficiency %	Locked-rotor currentA	Rated torque N.M	Locked-rotor torque	
12	18.5	2	35	0.9	90	254.3	60.24	2.2	
		4	36	0.86	90.5	270.8	120.4	2.2	
		6	37	0.83	90.7	275.9	180.7	2	
		8	42	0.76	88.6	264.7	242	1.9	
13	22	2	42	0.9	90	303.8	71.38	2	
		4	43	0.86	91	319.5	143.2	2.2	
		6	44	0.83	91.2	331.5	214.9	2	
		8	48	0.78	89.1	308.9	287.8	1.9	
14	30	2	58	0.93	90.3	364.2	97	2.2	
		4	60	0.86	92	411.9	194.7	2.2	
		6	61	0.84	91.5	408.8	292	2	
		8	63	0.79	91	415.8	389.8	2	
15	37	2	70	0.88	93.7	512.2	119.6	2	
		4	71	0.87	92	501.2	239.6	2.2	
		6	73	0.86	91.5	510	360.6	2.1	
		8	78	0.79	91.5	502.9	480.7	2.0	
16	45	4	85	0.87	92.8	604.8	290.8	2.2	
		6	86	0.86	92.5	597.8	438	2.1	
		8	94	0.79	92	610.5	584.7	2.0	
		4	104	0.87	92.6	741.6	355.8	2.2	
17	55	6	105	0.86	92.4	723.1	535.4	2.1	
		8	114	0.81	92.3	728.7	714.6	1.8	
		4	140	0.87	93.1	993.6	483.6	2.2	
18	75	6	147	0.86	93.2	981.4	726.3	2	
		8	152	0.81	92.8	977.5	974.5	1.8	
		4	167	0.89	93.5	1050	580	2	
19	90	6	176	0.87	93.5	1008	870	1.7	
		8	180	0.82	93.1	1090	1161	1.9	
		4	201	0.88	94.5	1200	710	1.8	
20	110	6	206	0.86	94.5	1230	1066	1.7	
		8	217	0.82	94.1	1324	1420	1.9	
		4	241	0.88	94.8	1395	850	1.8	
21	132	6	244	0.87	94.5	1440	1280	1.8	
		8	260	0.83	93.3	1927	1703	1.5	
		4	286	0.9	94.5	1800	1030	2.1	
22	160	6	294	0.88	94	1965	1550	1.8	
		8	314	0.83	93.3	2204	2064	1.5	

Parameter table of submersible motor(three-phase 380V 50Hz)								
No.	Motor power (kW)	Pole number	Rated current A	Power factor cosψ	Motor efficiency %	Locked-rotor current A	Rated torque N.M	Locked-rotor torque
23	185	4	333	0.9	94.6	1947	1191	2.0
		6	340	0.88	94	2204	1792	1.6
		8	362	0.83	93.8	2625	2380	1.5
24	200	4	359	0.9	94.6	2112	1288	2
		6	368	0.88	94	2484	1937	1.6
		8	390	0.83	93.9	2835	2574	1.5
25	220	4	396	0.89	95	2758.7	2132	2.2
		6	404	0.88	94.2	2812	1419.5	1.8
		8	430	0.83	93.9	3118	2831	1.6
26	250	4	445	0.9	95	2664	1607	1.7
		6	460	0.88	94.4	3105	2424	1.8
		8	488	0.83	94	3548	3218	1.6
27	280	4	498	0.9	95	2988	1800	1.7
		6	510	0.89	94.4	3428	2715	1.8
		8	548	0.83	94	3975	3604	1.6
28	315	4	560	0.9	95	3360	2025	1.7
		6	570	0.89	94.5	3735	3054	1.8
		8	615	0.83	94	4298	4457.4	1.6

## Installation method

### 1. Fixed base installation (P):

Fix the base on the foundation, fix the base with anchor bolts, and connect the outlet pipe. It is inconvenient to repair the single pump after running;

### 2. Mobile installation (Y, R):

It is used for first aid or maintenance and construction, flexible and convenient to operate. It can be operated by connecting a hose or a hard pipe with the pump base support. It can also be suspended for use with a sufficiently rigid drainage pipeline.

### 3. Automatic coupling installation (Z):

**The coupling device includes:** coupling base, coupling gusset, guide rod, and coupling pull rod.

**Automatic coupling installation:** The coupling device links the pump and pipeline without fasteners, making the connection and disconnection of the pump and coupling base simple.

#### Operation essentials:

(1) Lay the cement foundation and reserve the anchor bolt holes according to the installation drawing.

(2) Fix the coupling base, coupling rod and guide rod, and the coupling base needs to be poured twice.

(3) Connect the coupling gusset plate and pump body flange with bolts.

Whether to install or lift the pump, you only need to lift the lifting chain and let the gusset plate semi-circular hole slide along the guide rod.



The guide rod only bears the guiding force, this installation method is time-saving and effort-saving.

## Order description

To make the pump you choose more in line with working site requirements, users are warmly welcome to call our technical department.

#### Please specify when ordering:





1. Pump model, flow, head, speed, power, motor power, medium temperature, medium composition, medium density
2. Parts material: pump body, impeller
3. Installation method, outlet diameter
4. Please specify starting method in the order if there are some requirements.
5. The standard water pump cable is 9 meters, specify it if other lengths are required.
6. The complete set of supply parts is provided according to the determined installation method.
7. Necessary parts, optional parts and spare parts need to be ordered separately.
8. Follow the principle of "spread before turning" when connecting the spinal canal and the elbow joint on the discharge pipeline.
9. Fill in the selection form.

No.	Pump model:	Configuration: standard	Optional (specify in the order)
1	Flow: Q= m <sup>3</sup> /h	Starting method:	
2	Head: H= m	Wiring method:	
3	Pump immersion depth:h= m	Medium temperature :Normal °C; Max °C; Min °C	
4	Outlet diameter: mm	Corrosion component:	
5	Insulation class: F(standard) H(optional)	Oxide concentration(PPM):	
6	Motor rated power: kW	Sediment content:	
7	Voltage on site: V	Maximum particle diameter: mm	
8	Pump speed: r/min	Fiber type and length:	
9	Frequency: Hz	Ambient temperature:Normal °C; Mak °C; Min °C	



### Supply list

	Supply list	Installation method				
		Automatic coupling installation(Z)	Fixed base installation (P)	Hard pipe mobile installation(Y)	Soft pipe mobile installation(R)	Single pump
Complete supply parts	Pump (9-meter cable)	✓	✓	✓	✓	✓
	Coupling base	✓				
	Gusset plate	✓				
	Coupling rod	✓				
	Pump base (1pc/set)	✓	✓	✓	✓	✓
Essential parts	Guide rod	✓				
	Anchor bolt	✓	✓			
	Expansion bolt	✓				
	Hard pipe (1 pc/set)		✓	✓		
	Soft pipe (1 pc/set)				✓	
Optional parts	Submersible pump monitoring device	✓	✓	✓	✓	✓
	Stainless steel wire rope and rope clamp for lifting pump	✓	✓	✓	✓	✓
	Spinal tube	✓	✓	✓	✓	✓
	Mating flange	✓	✓	✓		✓
	Flange joint		✓	✓		✓
	Gate valve/butterfly valve	✓	✓	✓	✓	✓
	Check valve	✓	✓	✓	✓	✓
	Electric control cabinet	✓	✓	✓	✓	✓
	Terminal box	✓	✓	✓	✓	✓
	Float switch (liquid level)	✓	✓	✓	✓	✓
Spare parts	Impeller	✓	✓	✓	✓	✓
	Bearing	✓	✓	✓	✓	✓
	Mechanical seal	✓	✓	✓	✓	✓
	Seal ring	✓	✓	✓	✓	✓
	O-ring seal	✓	✓	✓	✓	✓







WQA50Hz performance curve chart





WQA50Hz performance curve chart







WQA50Hz performance curve chart




WQA50Hz performance curve chart





WQA50Hz performance curve chart



## WQA installation dimension drawing




## Pump appearance and mobile installation




## Flange coupling parts dimension table

No.	Model	Flange Connection Size			Coupling Base Size							H3	H4	H5	H6	H7	L	L1	L2	M	Φe	L3	L4	L6	L10	Φdxt (Outer diameter × Wall thickness)		
		D	D1	N1-Φd1	A	A1	B	B1	J	n2-Φd2																		
1	40	130	100		108	65	138	68	68	4-Φ15	195	120	14	150	225	185	70	35		65	125	85	13					
2	50	140	110	4-Φ14	197	168	208	130	120		250	165		265	215	110	42		66	135	90	15	Φ33×3					
3	65	160	130		238	190	252	155	135	4-Φ19	310	170	16	280	235	125	50		70	185	85	18						
4	80	190	150	4-Φ19	255	220	225	153	125		310	190		315	265	145	53		80	155	100	18						
5	100	210	170		293	265	258	175	140	4-Φ19	350	235	18	365	305	170	55		200	110	20							
6	150	265	225		285	410	300	210		4-Φ22	485	300	22	390					290	190	20		Φ48×3					
7	200	320	280	8-Φ19	400	300	445	350	250		550	325	22	440	410	260	285	60		330	195	20						
8	250	375	335	12-Φ19	460	360	555	430	325		635	310	24	450					395	215	20							
9	300	445	400	12-Φ23	550	415	570	410	345	4-Φ25	740	400	30	570	480	305	340		110	395	225	23						
10	350	505	460	16-Φ23	580	420	615	400	350		860	490	33	680	500	320	360	65		435	230	25	Φ60×3					
11	400	565	515	16-Φ28	630	490	665	510	430		960	560	36	775					480	235	25							
12	500	670	620	20-Φ28	732	570	752	550	475	4-Φ28	1160	655	38	900	750	660	460	78	Φ20		565	250	26	Φ76×3.5				
13	600	780	725	20-Φ31	830	720	850	700	590	4-Φ33	1320	710	40	1020	830	740	560			660	275	30						

Adjust according to pump model



Hard pipe(double flange joint/elbow)  
mobile installation



Soft pipe(joint) mobile installation

**WQA sewage pump series**

No.	WQA model	Diameter	Power	Rotating speed	Voltage	Passable particle diameterD	Appearance dimension table(mm)						Weight kg	Pressure grade of pump outlet flange kg
		mm	kW	r/min	V	mm	L5	B2	H	H1	H2	L8	L9	
1	40WQA10-10-0.75	0.75	0.75	1100	220	135	200	460	380	110	90	95	100	23
2	40WQA8-15-1.1	1.1	40	1100	200	150	240	490	400	125	100	110	115	24
3	40WQA15-12-1.1	1.5	40	1100	220	135	200	460	380	110	90	95	100	25
4	40WQA12-15-1.5	1.5	40	1100	200	145	230	545	455	120	105	95	105	29
5	50WQA10-7-0.55	0.55	50	1100	220	160	230	580	490	120	105	100	100	24
6	50WQA10-10-0.75	0.75	50	1100	200	170	230	590	500	125	105	110	115	23
7	50WQA8-15-1.1	1.1	50	1100	220	160	230	570	480	125	105	110	115	24
8	50WQA15-12-1.1	1.1	50	1100	200	170	230	515	515	130	110	110	115	25
9	50WQA15-16-1.5	1.5	50	1100	220	160	230	545	455	120	105	95	105	29
10	65WQA25-8-1.5	1.5	65	1100	200	170	230	580	490	120	105	100	115	23
11	50WQA15-22-2.2	2.2	50	1100	200	180	230	605	515	130	105	125	140	38
12	50WQA25-15-2.2	2.2	50	1100	200	190	230	635	535	140	120	110	120	37
13	65WQA30-11-2.2	2.2	65	1100	200	200	230	665	565	140	115	110	125	38
14	80WQA40-10-2.2	2.2	80	1100	200	210	230	590	500	120	105	110	115	41
15	100WQA50-7-2.2	2.2	100	1100	200	220	230	635	535	140	120	110	120	43
16	50WQA15-30-3	3	50	1100	200	230	230	665	565	140	115	110	125	43
17	50WQA25-20-3	3	50	1100	200	240	230	690	590	155	135	125	140	6
18	50WQA15-35-4	4	50	1100	200	250	230	730	620	155	135	125	135	95
19	50WQA25-28-4	4	50	1100	200	260	230	760	650	155	135	125	135	95
20	50WQA20-40-5.5	5.5	50	1100	200	270	230	790	680	155	135	125	135	95
21	50WQA25-35-5.5	5.5	50	1100	200	280	230	820	710	155	135	125	135	95
22	50WQA25-40-7.5	7.5	50	1100	200	290	230	850	740	155	135	125	135	95
23	65WQA35-15-3	3	65	1100	200	300	230	880	770	155	135	125	135	95
24	65WQA35-20-4	4	65	1100	200	310	230	910	800	155	135	125	135	95
25	65WQA30-30-5.5	5.5	65	1100	200	320	230	940	830	155	135	125	135	95
26	65WQA30-35-7.5	7.5	65	1100	200	330	230	970	860	155	135	125	135	97
27	80WQA40-13-3	3	80	1100	200	340	230	1000	900	155	135	125	135	44
28	80WQA50-15-4	4	80	1100	200	350	230	1030	930	155	135	125	135	63
29	80WQA65-17-5.5	5.5	80	1100	200	360	230	1060	960	155	135	125	135	76
30	80WQA45-25-7.5	7.5	80	1100	200	370	230	1090	990	155	135	125	135	103
31	100WQA60-9-3	3	100	1100	200	380	230	1120	1020	155	135	125	135	55
32	100WQA80-8-4	4	100	1100	200	390	230	1150	1050	155	135	125	135	64
33	100WQA65-15-5.5	5.5	100	1100	200	400	230	1180	1080	155	135	125	135	76
34	100WQA80-17-7.5	7.5	100	1100	200	410	230	1210	1110	155	135	125	135	103
35	100WQA45-25-7.5	7.5	100	1100	200	420	230	1240	1140	155	135	125	135	125
36	150WQA100-8-5.5	5.5	150	1100	200	430	230	1270	1170	155	135	125	135	140
37	150WQA100-12-7.5	7.5	150	1100	200	440	230	1300	1200	155	135	125	135	140
38	150WQA130-8-5.5	5.5	150	1100	200	450	230	1330	1230	155	135	125	135	145
39	150WQA150-10-7.5	7.5	150	1100	200	460	230	1360	1260	155	135	125	135	145

30

**WQA installation dimension table**

No.	WQA model	Diameter	Power	Rotating speed	Voltage	Passable particle diameterD	Appearance dimension table(mm)						Weight kg	Pressure grade of pump outlet flange kg	Full-head?		
		mm	kW	r/min	V	mm	L5	B2	H	H1	H2	L8	L9				
1	65WQA20-56-11	65	11	1100	200	220	320	800	600	160	145	155	160	153	6	NO	
1	80WQA40-45-11	80	11	1100	200	240	320	830	630	160	145	155	160	160	6	NO	
2	80WQA45-55-15	80	15	1100	200	15	280	300	1170	880	155	155	160	175	246	YES	
2	80WQA50-45-18.5	80	18.5	1100	200	22	280	300	1170	880	155	155	160	175	255	6	NO
2	80WQA50-65-22	80	22	1100	200	20	240	320	830	630	160	145	155	160	172	6	NO
3	80WQA80-53-22	80	22	1100	200	15	340	380	1380	880	205	210	220	230	263	6	NO
3	100WQA40-45-11	100	11	1100	200	15	280	300	1170	880	155	155	160	175	295	6	NO
4																	

WQA installation dimension table

No.	WQA model	Diameter	Power	Rotating speed	Voltage	Passable particle diameter D	Appearance dimension table(mm)						Weight kg	Pressure grade of pump outlet flange	Full-head?	
		mm	kW	r/min	V	mm	L5	B2	H	H1	H2	L8	L9	L7		
13	200WQA340-7-11	11	11												295	
13	200WQA400-8-15	15	15	1475	80	420	380	1180	890	245	240	280	310	315	10	
13	200WQA400-10-18.5	200	18.5	22											380	
13	200WQA400-12-22	11													395	
14	200WQA300-13-15	15	15	1475	85	420	300	1130	830	205	230	270	300	315	6	YES
14	200WQA300-16-18.5	200	18.5	22											380	
14	200WQA340-16-22	22													395	
15	200WQA340-22-30	30													655	
15	200WQA400-24-37	200	45	1475	80	460	400	1640	1060	215	250	280	310	738	6	
15	200WQA400-28-45	200	45												682	
15	200WQA400-34-55	55													771	
16	200WQA600-32-75	75	1475	80	560	400	1900	1230	305	340	365	1145		1070	6	NO
16	200WQA600-36-90	200	90												1145	
17	200WQA480-50-110	110													1585	
17	200WQA500-58-132	200	132	1475	75	550	400	2150	1390	270	325	340	360	1652	10	
17	200WQA600-64-160	160													1757	
18	250WQA380-7-11	11													305	
18	250WQA400-10-15	15	1475	75	450	460	1390	890	225	250	300	335	325	6	YES	
18	250WQA480-10-18.5	18.5													388	
19	250WQA600-12-22	22													405	
19	250WQA600-15-37	37	1475	80	530	400	1650	1070	210	265	315	360	700	755	6	
19	250WQA600-18-45	45													772	
20	250WQA600-24-55	55													788	
20	250WQA600-13-30	30	980												690	
21	250WQA600-14-37	37													720	
21	250WQA650-16-45	45	980	90	570	550	1970	1300	285	300	335	370	975	10	NO	
22	250WQA700-20-55	55													1024	
22	250WQA750-30-90	90	1475	85	520	460	1935	1270	255	280	315	345	1095	6	YES	
23	250WQA600-40-110	110	980		40	630	650	2280	1530	270	370	420	445	1865	10	
24	250WQA650-40-132	132	1475	100	660	460	2180	1430	280	325	360	390	1615		NO	
24	250WQA800-40-160	160													1685	6
24	250WQA800-50-160														1788	

WQA installation dimension table

No.	WQA model	Diameter	Power	Rotating speed	Voltage	Passable particle diameter D	Appearance dimension table(mm)						Weight kg	Pressure grade of pump outlet flange	Full-head?		
		mm	kW	r/min	V	mm	L5	B2	H	H1	H2	L8	L9	L7			
25	250WQA600-68-18.5	185					70	600	460	2270	1510	250	350	380	405	1855	
25	250WQA600-74-20.0	250	200	1475											1896	10	
25	250WQA600-80-22.0	220													1923		
26	300WQA600-6-15	15													510		
26	300WQA600-8-18.5	300	18.5	980			90	575	500	1500	1000	255	325	380	440	542	10
26	300WQA700-8-22	22													558		
27	300WQA900-9-37	37	980				90	600	550	1970	1300	285	340	380	425	983	
27	300WQA900-12-45	45													1035		
27	300WQA900-17-55	55													1635		
28	300WQA900-22-75	75					70	700	650	2180	1420	270	415	475	525	1721	10
29	300WQA900-27-110	110					45	630	650	2300	1540	270	400	435	475	1997	
29	300WQA900-36-132	132	980												1891		
30	300WQA900-20-75	75					120	565	525	1985	1320	275	325	390	440	1100	10
30	300WQA900-24-90	90	1475	100	670	525	2205	1450	285	350	400	445	1717		1175	10	
31	300WQA1000-25-110	110					380	100							1650		
31	300WQA1000-30-132	132	1475												1840		
31	300WQA1100-36-160	160													1910		
32	300WQA1250-36-185	185													1950		
32	300WQA1300-38-200	200	1475		70	650	525								2236		
32	300WQA1300-50-250	250													2340		
32	300WQA1400-52-280	280													792		
33	350WQA1100-8-37	37	980		110	740	520	1750									

## WQA installation dimension table

No.	WQA model	Diameter mm	Power kw	Rotating speed r/min	Voltage V	Passable particle diameter D mm	Appearance dimension table(mm)								Pressure grade of pump outlet flange	Full- head?	
							L5	B2	H	H1	H2	L8	L9	L7	kg		
	350WQA1100 - 35 - 160	160														2570	
36	350WQA1100 - 40 - 185	185														2620	
	350WQA1200 - 40 - 200	200	980			55	800	750	2730	1800	355	450	500	540	2800	10	
36	350WQA1400 - 42 - 220	220													2990	3070	
	350WQA1600 - 40 - 250	250													3070	3070	
36	350WQA1700 - 42 - 280	280													3070	3070	
37	400WQA1600 - 12 - 75	75	90	980		120	850	650	2280	1520	350	495	565	635	1766	10	
	400WQA1800 - 13 - 90	90	110												1855	2024	
37	400WQA1900 - 15 - 110	110	132												2130	2130	
	400WQA2400 - 14 - 132	132													2130	2130	
38	400WQA1600 - 25 - 160	160	185	980		120	860	650	2750	1820	330	490	560	615	2670	10	
	400WQA1800 - 28 - 185	185	400												2730	2730	
38	400WQA1900 - 30 - 200	200													2850	2850	
	400WQA2600 - 26 - 220	220													2995	2995	
39	400WQA2200 - 28 - 250	250	400	980		150	850	670	2800	1870	335	470	555	635	3070	10	
	400WQA2200 - 32 - 280	280													3070	3070	
40	400WQA1200 - 6 - 30	30	37	740		100	850	660	2060	1390	350	500	580	650	1700	10	
	400WQA1300 - 7 - 37	37	45												1737	1737	
40	400WQA1400 - 8 - 45	45													1816	1816	
	400WQA1500 - 10 - 55	55													1910	1910	
41	400WQA2000 - 9 - 75	75	90	740		380									2050	2050	
	400WQA2200 - 10 - 90	90	110												2350	2350	
41	400WQA2200 - 12 - 110	110													2680	2680	
	400WQA2200 - 15 - 132	132													2735	2735	
41	400WQA2400 - 17 - 160	160	185	740		100	800	800	2520	1760	435	475	575	655	3000	10	
	400WQA2500 - 18 - 185	185	400												3200	3200	
41	400WQA2500 - 19 - 200	200													3400	3400	
	500WQA2700 - 7 - 90	90													3400	3400	
42	500WQA3000 - 8 - 110	110	132	740		100	800	800	2910	1990	435	475	575	655	3130	10	
	500WQA3000 - 10 - 132	132													3210	3210	
42	500WQA3000 - 14 - 160	160													3290	3290	
	500WQA3000 - 17 - 185	185													3470	3470	
42	500WQA3000 - 18 - 200	200													3550	3550	
	500WQA3000 - 20 - 220	220													3740	3740	
43	500WQA3000 - 23 - 250	250	500	740		95	1000	800	2770	1840	365	620	710	790	3380	10	
	500WQA3000 - 25 - 280	280													3460	3460	
43	600WQA3500 - 12 - 185	185													3640	3640	
	600WQA4000 - 12 - 200	200													3720	3720	
44	600WQA4000 - 14 - 220	220													3910	3910	
	600WQA3800 - 17 - 250	250													4090	4090	
44	600WQA4200 - 16 - 280	280															
	600WQA4200 - 20 - 315	315															

## Installation instructions

## ● Installation

1. Check the pump, motor, and fasteners before installation.
2. The weight of the pipeline should not be added to the pump to avoid deformation, vibration, etc.
3. The anchor bolts must be tightened during installation, and the guide rod and coupling gusset must be fixed.

## ● Start up

1. The liquid level shall not be lower than the minimum liquid level when starting, the minimum liquid level is shown in the installation diagram.
2. Start the motor, check rotation direction. The pump should rotate clockwise looking down from the motor side.
3. (1)For centrifugal type impeller, close the valve and pressure gauge on the outlet pipeline.  
(2)For mixed-flow and axial-flow impellers, open the valve according to the pump model.
4. Start the motor, turn on the pressure gauge. As the speed rises, gradually adjust the valve opening extent on the outlet pipe to achieve the required flow.

## ● Stop

1. First close the outlet valve, close the pressure gauge, and then cut off the motor power supply.
2. In case of long-term shutdown, it is recommended to lift the pump up, clean it up, put it in a dry place, and keep it properly.


## ● Maintenance

1. Check the motor current value regularly  
When the ambient temperature is motor rated temperature, the current must not exceed the rated current.  
When the ambient temperature is lower than motor rated temperature, the current value can be slightly increased, please refer to the motor data for details.  
When the current is abnormal, please find out the cause immediately.
2. After long-term operation, the pump should be shut down for inspection due to the wear of mechanical seals, bearings, impellers, seal rings and other parts. And wearing parts like mechanical seals, bearings, O-rings and seal rings should be replaced. The general inspection cycle is normally one year. The service life of the mechanical seal is determined by the on-site working conditions, and the designed service life is 8000 hours.
3. Check the oil chamber regularly. If oil emulsification occurs, replace 32# engine oil in time. Executive standard: GB443-89


## Diving cable connection

When the length of the cable cannot meet users' installation requirements, an external cable is required. The wiring should be operated by a full-time electrician. The cross-sectional area of the cable is determined by the installation length, motor power and starting method. The motor cable and the external cable joints are required to be reliably sealed, insulated, and have certain strength. The wiring process is briefly as follows.

1. Strip the cable on the sewage pump as shown in the figure below, and strip the copper core by 30~35mm long. Wipe it with gauze and copper wire to make it shine. Also strip the copper wire of the external three-core cable by 30~35mm, and wipe it clean with gauze.




2. As shown in the figure below, insert the stripped copper wire parts of the three-core cable and external cable together, and then use a thin copper wire to bind tightly as shown in the figure, cut off the remaining part, flatten it with scissors, and do not tie your hands. Tie the three wires in the same way.




3. Prepare a small iron box or small iron pot that can stick the three wire ends, put solder into the pot and heat it on fire until it melts, and then apply proper amount of soldering oil to the three wire ends, quickly put into the pot and weld it firmly. The surface of the welding head is required to be smooth, free of burrs and false welding. If the welding is not strong or not smooth, it should be re-welded until it meets the requirements.

4. As shown in the figure below, when wrapping with polyester insulating tape, be sure to press half of the first circle (shift wrapping method) for 8~12 layers. After wrapping, wrap two more plastic tape layers for strength protection.



5. As shown in the figure below, wrap the three wires together with plastic tape by two layers. The first layer exceeds the end of each wire insulation layer by more than 50mm, and the second layer exceeds the first layer by more than 50mm. It needs to be tightly wound to exclude air space to the largest extent.



6. After wrapping, take a basin of cold water and completely soak the banded thread in the water. Measure the insulation with a 500V megohmmeter after 12 hours. The insulation should not be less than 50 megohms, otherwise it should be re-wrapped until it meets the requirements.

7. The grounding wire of the submersible electric pump also needs to be wrapped according to the wiring process requirements of the submersible cable.

**Note:** Customer needs to calculate voltage drop when connecting additional cable. Pay attention to voltage change during operation which should be generally controlled within  $\pm 5\%$  of the rated voltage.

### Common malfunctions and solutions

Malfunctions	Cause analysis	Solutions
None or insufficient pump water flow	<ul style="list-style-type: none"> <li>○ Motor reverse rotation</li> <li>○ The impeller passage or pipeline is blocked</li> <li>○ Tubing resistance is too large</li> <li>○ The impeller is severely worn</li> <li>○ Gas mixed in the medium</li> <li>○ Check valve direction is reversed</li> <li>○ Head on customer's site is not enough</li> <li>○ Coupling leaks</li> </ul>	<ul style="list-style-type: none"> <li>○ Adjust two phase power sequence</li> <li>○ Remove impurities, it is best to add a thin grille at the water inlet</li> <li>○ ①Reduce pipeline bends, increase diameter for long pipe ②Check whether the valve is open ③Check whether the impeller is scraped</li> <li>○ Replace the impeller</li> <li>○ Exhaust gas, increase liquid depth to reach the minimum water level requirement "<math>\Delta</math>"</li> <li>○ Adjust the direction of the check valve</li> <li>○ Check whether customer's test method is correct after excluding the above reasons</li> <li>○ Check whether the installation is proper and ensure that the guide rod is vertical</li> </ul>
The pump fails to start	<ul style="list-style-type: none"> <li>○ Lack of phase</li> <li>○ Impeller stuck</li> <li>○ Short circuit of winding joint or cable</li> <li>○ Stator winding burnt out</li> <li>○ Control cabinet error</li> <li>○ Low power supply voltage</li> </ul>	<ul style="list-style-type: none"> <li>○ Check the circuit, eliminate problem of lack-phase</li> <li>○ Clear impurities</li> <li>○ Recover after checking with ohmmeter</li> <li>○ Replace the winding or stator, it is better to add a temperature measuring element</li> <li>○ Check the control cabinet and remove fault</li> <li>○ Solve power supply voltage problems</li> </ul>
Large fluctuations in discharge pressure	<ul style="list-style-type: none"> <li>○ The liquid level of suction pool is too low</li> <li>○ The suction elbow is not tightly sealed, making air entering the pump</li> <li>○ Medium temperature is high</li> </ul>	<ul style="list-style-type: none"> <li>○ Control the minimum liquid level of the suction pool</li> <li>○ Check the pipe connection and eliminate the cause</li> <li>○ Reduce medium temperature. If the temperature cannot be lowered, increase the pump minimum liquid level and replace high-temperature motor</li> </ul>
Overloading current	<ul style="list-style-type: none"> <li>○ The head of the selected pump exceeds the actual head. Or the head of the device is greatly reduced, indicating that the pump is running at a large flow rate</li> <li>○ The density or viscosity of the medium is too high</li> <li>○ Bearing is damaged</li> <li>○ There are impurities at the neck ring</li> <li>○ Power supply voltage is too low</li> </ul>	<ul style="list-style-type: none"> <li>○ Reduce outlet pipe valve opening or the outer diameter of small impeller, or replace a pump that matches the actual working conditions on site</li> <li>○ Dilute medium</li> <li>○ Replace bearing</li> <li>○ Clean up impurities</li> <li>○ Solve power supply voltage problems</li> </ul>
Heating bearing	<ul style="list-style-type: none"> <li>○ Bearing wears</li> <li>○ Bearing grease is too little or too much</li> <li>○ Grease is degenerative</li> </ul>	<ul style="list-style-type: none"> <li>○ Replace the bearing</li> <li>○ The amount of grease added is about 1/3~1/2 of the oil chamber cavity</li> <li>○ Change grease</li> </ul>